Location and Vicinity Map Guide



Website: https://www.tn.gov/content/tn/tdot/roadway-design/designstandards/design-cadd-files.html

Email: TDOT.CADDSupport@tn.gov

Location Maps

This document provides the directions to set up a location map in a Microsoft Word document as per the TDOT Roadway Design Guidelines.

The location map is first prepared in **MicroStation** using a standard 8.5 x 11 form cell with a design and/or raster map file attachment. A raster image file of the completed location map is then created in MicroStation which can then be inserted into a **MicroSoft Word** document.

To use the TDOT Design Division county map files, download from https://www.tn.gov/content/tn/tdot/roadway-design/design-standards/design-cadd-files/tennessee-map-files-for-microstation.html.

The files are listed by county name. All maps are in NAD 83 English mapping coordinates as set up in the standard TDOT Design Division English MicroStation DGN seed file. Graphics are set for scale 1" = 5280'

Attach the County Map(s) to the Location Map Form

- 1. Create a new DGN file (2D Seed) for the location map.
- 2. Reference your alignment DGN file to the location map DGN file.
- 3. Set the active scale = 5280.
- 4. Place a location map cell so the alignment is centered in the map area. In MicroStation running the TDOT interface, go to TDOT > Permits & Forms or in Geopak's D&C Manager go to Drafting Standards > Sheets > Permits & Forms.
- Reference the county DGN file to the location map DGN file. In MicroStation go to File > Reference. In the Reference dialog box, go to Tools > Attach and select the county DGN file. Set Attachment Method to Coincident (or Coincident World) and select OK.

NOTE: Sometime the actual location does not always line up with the roadway alignment when referencing. To correct such issue, user shall use **Move** or **Rotate** tools in the **Reference** dialog box under **Tools** to adjust the county map before clipping.

- 6. Fence the map area you need on the location map and do a clip boundary for the DGN county file.
 - a. In the Reference File dialog box, select the county map DGN, go to Tools > Clip
 Boundary. In the MicroStation Tool Settings box set Method to Active Fence, click on Use
 References Dialog List and data point to accept.

NOTE: Sometime the actual location does not always line up with the roadway alignment when referencing. To correct such issue, user shall use **Move** or **Rotate** tools in the **Reference** dialog box under **Tools** before clipping.

- In MicroStation, turn off level DESIGN SCRATCH User 1, (#30), in the county DGN reference and go to File > Save Settings.
- 8. Annotate & move the map as needed

Note: The location map will plot at 1" = 5280'.

Generate JPG Image File of Location Map

- 1. In the MicroStation location map DGN file, set the view attributes to Line Weights on, Data Fields off, Fill on.
- 2. Create a fence by snapping to the green snap points on the location map cell. This will place the fence just inside of the 8.5" x 11" border lines.
- Use MicroStation Print to create the JPG file. Go to File > Print. Then go to File > Select Bentley Driver. In the MicroStation Print dialog, attach the Tdotjpeg.pltcfg plotter driver.
- 4. Set the **Print Scale** to 5280 or otherwise to match the map scale.

Print (Tdotjpeg.pltcfg) File Settings PenTable	
General Settings	
Area: Fence Rasterized	
View: View 1 -	
Color: Monochrome Copi <u>e</u> s: 1	
Pen table: TdotPlot.tbl	
Printer and Paper Size Bentley driver • <u>A</u> Paper: Letter • Usable area: 8.5 x 11 in. Portrait • Create plot file •	Show design in preview
Print Scale and Position Scale: 5280.000000 Size: 8.000 10.501 in. Origin: 0.000	er) to 5280.000000 ' (design) timize <u>Rotation</u> . <mark>None ▼</mark> - <u>o</u> enter

5. Go to File > Print (first icon) and save the JPG file to the projectfolder.

Insert JPG Image File into Microsoft Word Document

- 1. Open the Word document for the location map. Go to the **Page Layout** ribbon menu and click on **Margins**. Choose **Custom Margins** and set the margins on all sides to 0.25 inches.
- 2. Go to the **Insert** ribbon menu and click on **Picture**. Navigate to & select the image file created with MicroStation Print.
- 3. The image will come in to the available margin space in the Word file and if you used the green snap points on the form then the image size will be 8" X 10.5" which will be to scale. After insertion the **Picture Tools** ribbon menu is opened automatically and **Size** at the far right shows the width and height. For other map sizes, adjust these values to achieve the correct scale. (Map dimension in inches = Width in MicroStation / Scale).

Vicinity Maps

In the Permit Applications process for a project a Vicinity Map usually is included with the Permit Sketches. An example of how the Vicinity Map should look is shown in Fig.3-8 in <u>Roadway Design</u> <u>Guidelines Section 3.</u> A Vicinity Map shows the area of the project superimposed on a Quadrangle Map. The Quadrangle Maps are in the folder:

file://ag03sdcwf00010.net.ads.state.tn.us/PROJECTS/QuadSheets/Nad83%20Named./.



The Quad Maps are in the form of raster files. There is also a MicroStation file named 83StatePlaneIndexV8. This file contains an outline of the state of Tennessee with blocks named corresponding to the raster Quad Maps.



Attach the Quad Map(s) to the Vicinity Map Form

- 1. Copy 83StatePlaneIndexV8.dgn to your project folder.
- 2. Create a new DGN file (2D Seed) for the vicinity map.
- Reference your alignment DGN file and 83StatePlaneIndexV8.dgn to the vicinity map DGN file.
- 4. Set the active scale = 2000.
- 5. Open the vicinity map DGN file and locate your project in the state map. In this example the project is located in Rutherford County in the "Murfreesboro" Quad block.



6. In the Quad Map folder locate the raster file corresponding to the block in which the project is located. Copy this file to your project folder.

7. Attach the raster file by selecting File> Raster Manager. Then select File> Attach> Raster. Browse to select the file you copied to your project folder earlier. Select Attach and the appropriate Quad Map will appear in the correct block location. The reference display for the state plane index file can be turned off.



NOTE: When referencing alignment to raster file, the alignment and desire vicinity area do not always line up. To line them up, user can utilize **Move** & **Rotate** tools under **Raster Manager** dialog before clipping.

Place a vicinity map cell so the alignment is centered in the map area. In MicroStation running the T.D.O.T. interface, go to T.D.O.T > Permits & Forms or in GEOPAK's D&C Manager go to Drafting Standards > Sheets > Permits & Forms.



(Note: This example shows the Portrait view sheet with the raster reference turned off.)

9. Drop status on the sheet cell to move the flags to their proper locations.

10. Clip the raster file at the display boundary.

To clip the raster file, select Clip under Edit in Raster Manager dialog and then choose

🚯 Clip	—	\times
Method	Fence	-
Mode	Clip Boundary	-

Fence Method/ Clip Boundary Mode. Fence desire boundary area and data point to clip.



11. Complete by filling all information in the data fields.

Generate JPG Image File of Vicinity Map

- In the MicroStation vicinity map DGN file, set the view attributes to Line Weights on, Data Fields off, Fill on.
- 2. Create a fence by snapping to the green snap points on the location map cell. This will place the fence just inside of the 8.5" x 11" border lines.
- Use MicroStation Print to create the JPG file. Go to File > Print. Then go to File > Select Bentley Driver. In the MicroStation Print dialog, attach the Tdotjpeg.pltcfg plotter driver.
- 4. Set the **Print Scale** to 2000 to match the map scale.
- 5. Change the **Color** to True Color. This allows for the Vicinity Map to be printed in color and not black and white.

🚧 Print (Tdotjpeg.pltcfg)	– 🗆 X
File Settings PenTable	
🍓 🗣 🗄 📑 💕 🔹 ◀	
General Settings	Mar Same
Area: Fence Rasterized	
View: View 1	
Color: Monochrome Copi <u>es</u> : 1	and the second s
Pen table: TdotPlot.tbl	
Printer and Paper Size	
Bentley driver 🔻 🤇	
Paper: Letter 👻	
Usable area: 8.5 x 11 in.	
Portrait	Show <u>d</u> esign in preview
Print Scale and Position	
Scale: 2000.00 Q 1 in. (pap	er) to 2000.00 ' (design)
Size 8.000 10.501 in. ++ Ma	ximize <u>R</u> otation: None -
<u>O</u> rigin: 0.000 0.000 in.	o- <u>c</u> enter

6. Go to **File > Print** (first icon) and save the JPG file to the projectfolder.

Insert JPG Image File into Microsoft Word Document

- 1. Open the Word document for the location map. Go to the **Page Layout** ribbon menu and click on **Margins**. Choose **Custom Margins** and set the margins on all sides to 0.25 inches.
- 2. Go to the **Insert** ribbon menu and click on **Picture**. Navigate to and select the imagefile created with MicroStation Print.
- 3. The image will come into the available margin space in the Word file. If you used the green snap points on the form, the image will be to scale and at a size of 8" X 10.5". After insertion, the **Picture Tools** ribbon menu is opened automatically. The **Size menu** is at the far right and shows the width and height. For other map sizes, adjust these values to achieve the correct scale. (Map dimension in inches = Width in MicroStation / Scale).

Permit Sketch Printing

0.46435-2414-04 N # 124428.00

WIT

WET

딦

1. Fence in the area to print 0000 ä a de la composición d

2. Select Print

a.

3. Area should automatically be fence but can be changed if not.

3 SPAN CONSISTS

E

- 4. Select magnifying glass a. Select TDOTPDFFULC or TDOTPDFFUL
- 5. Change color to monochrome
- Changed paper to PDF Permit Full
 Select maximize box

📕 Print (Tdotpdffulc.pltcfg)	– 🗆 X
<u>File</u> Settings <u>P</u> enTable	
🍓 🗣 🕀 🔁 📢	
General Settings	
Area: Fence Rasterized	
View: View 1 👻	a state of the sta
Color: Monochrome Copies: 1	
Pen table: TdotPlot.tbl	
Printer and Paper Size	A state of the sta
Bentley driver 👻 🔍	
Paper: PDE Permit Full	All and a second s
Lisable area: 8 346 x 10 847 in	
Portrait Create plot file	Show <u>d</u> esign in preview
Print Scale and Position	
Scale: 100.00 Q 1 in (pap	er) to 100.00 ' (design)
	(design)
Si <u>z</u> e: 8.346 10.847 in. +++ Max	kimize <u>R</u> otation: None v
Origin: 0.000 0.000 in. 🗸 Auto	- <u>c</u> enter

- 8. Go to settings print attributes
 a. Mark line weights
 b. Unmark Data Fields

Print Attributes		
Clip Back Clip Front Clip Volume Clip Volume Dimensions Data Fields Displayset Fast Cells Fast Curves Fill	 Level Overrides ✓ Line Styles ✓ Line Weights ✓ Pattems Points ✓ Tags ✓ Text Text Nodes Transparency 	
 Print broken associations with different symbology Apply print color mode to raster Use view background color when rendering 		
Print border	Print fence	
Border comment:		
<u>O</u> K	Cancel	

- 9. Select the print icon
 - a. The output file naming shall include .pdf extension such as PermitSketchexample.pdf
 - b. Click save.